General Specifications mirage





Characteristics	Mirage TruBalance		
Description	 Structured prefinished hardwood flooring Incomparable tongue and groove fit for remarkable uniformity Micro-V bevel (on 4 sides) 		
Thickness	3/4" (Sawn hardwood layer 5/32", SPF Quarter sawn core layer 17/32" and wood backing board 1/16")		
Width	5" 6-1/2" 7-3/4"		
Length ¹	Lengths from 20" (511 mm) to 82" (2,086 m	nm)	Lengths from 23" (590 mm) to 82" (2,086 mm)
Installation	Nailed, stapled, glued down or floated installation** (above, on or below grade)		
Subfloor	Wood, concrete or radiant heat system		
Species	5 species: Maple, Red Oak, White Oak, Hickory, Walnut		
Grade	Exclusive: Wood planks with some pronounced and nuanced coloration. The Exclusive grade offers a range of color variation. ⚠ Character: These floors are appreciated for their pronounced color variation. They feature open and closed knots, mineral streaks, cracks, surface holes, and other character or milling marks. Some distinctive marks may become prominent over time due to changes in the environment.		
Color choice (refer to 2023 Mirage Collections)	Some products may not be available. Ask your Mirage representative or consult the <u>Product Chart</u> .		
Finish	Finishing system made of aluminum oxide and nanosilica particle composites suspended in UV cured polyurethane. • DuraMatt' (5% gloss) • Nanolinx' HD • Cashmere** (18% gloss) • Nanolinx' Commercial (18% gloss) UV Protection: All products Static Friction Coefficient (ASTM-D-2047): Slippery resistance superior to 0.5		
Applicable standards	Surface Burning (ASTM-E-84): Surface Burning (ULC-S-102-2):		
Applicable stalladids	• FSI (Flame Spread Index) 90 Class C • FSR (Flame Spread Rating) 107 • SD (Smoke Development) 80 • SDC (Smoke Development Classification) 311		
	Critical radiant flux (ASTM-E-648-94a): R value: R 0.86 to 0.89 (depends on wood species) 0.38 watt/cm² (depends on wood species) cies)		
	Formaldehyde and VOC emissions (CDPH 1.2, 2017): Target product group (TruBalance) conform		
Provenance	Made in St-Georges, Qc, Canada.		
Use	Residential, light commercial or commercial		
Accessory	Round Stair nosing, Square Stair nosing, Round Reducer, Threshold, "T" molding, Quarter round		
	Acoustitech underlayments are recommended by Mirage. To know more about the minimum criteria needed regarding the recommended waterproof acoustic underlayment, please refer to the Technical Newsletter #20 in the Guides and Support section at miragefloors.com .		
Warranty	 Structural lifetime limited warranty (For the glued down and nailed/stapled installation relative humidity must be maintained within a range of 25% and 80%. For the floated installation relative humidity must be maintained between 30% and 60%). 35-year finish warranty for residential applications 5-year finish warranty for commercial applications with Nanolinx* Commercial 		
Packaging	5"	6-1/2"	7-3/4"
Content of a box Size of a box Weight of a box Content of a pallet Size of a pallet	22.70 sq. ft. 83" L x 10-1/2" W x 3-1/4" H 42 to 45 lbs 48 boxes = 1,089.60 sq. ft. (4 boxes/W x 12 boxes/H) 83" L x 42" W x 42" H	• 14.75 sq. ft. • 83" L x 7" W x 3-1/4" H • 27 to 31 lbs • 72 boxes = 1,062.00 sq. ft. (6 boxes/W x 12 boxes/H) • 83" L x 42" W x 42" H	• 17.60 sq. ft. • 83" L x 8-1/4" W x 3-1/4" H • 32 to 36 lbs • 60 boxes = 1,056.00 sq. ft. (5 boxes/W x 12 boxes/H) • 83" L x 42" W x 42" H
Relative species hardness			
NWFA Janka Test Hardness test (ASTM-D-143) Red Oak 1,290 lbs* - 100% *lbs = Applied force in pounds	 Walnut 1,010 lbs - 22% softer Red Oak 1,290 lbs - average hardness White Oak 1,360 lbs - 5% harder Maple 1,450 lbs - 12% harder Hickory 1,820 lbs - 41% harder 		

Toll free: 1-800-463-1303

^{*} Cashmere is a registered trademark used under license.

* For floated installation, please review the TruBalance installation Guide available on Mirage website in the Guides and support section.

** For floated installation, please review the TruBalance installation Guide available on Mirage website in the Guides and support section.

** For floated installation, please review the TruBalance installation Guide available on Mirage website in the Guides and support section.